



INTERNATIONAL SAFETY EQUIPMENT, INC.

Post Office Box 585 - Devault, PA. 19432-0585 U. S. A.

Voice: 610. 935. 8866

f. 610. 590. 0108 – e. Sales@System99.com - w. www.System99.com



SYSTEM *99* ~ BELAY INSTRUCTIONS



MANDATORY: O. S. H. A. REQUIRES A “BELAY” (BACK UP REDUNDANT FALL PROTECTION SYSTEM) ~ FOR WORK POSITIONING, (WHICH IS ANYTIME YOU ARE STOPPED TO WORK 3 FT. [OR MORE] ABOVE THE GROUND).

#1) THE TOP ANCHOR ~ POINT FOR THE “BELAY” ~ MUST BE ABLE TO SUPPORT 6,000 POUNDS ... (CONSULT AN ENGINEER TO BE SURE). ... IF YOU MUST RUN THE LONG ROPE OVER AN EDGE **BE SURE TO “PAD”** THE EDGE WHERE THE ROPE WILL MAKE CONTACT. USE A PIECE OF PLASTIC, A SLIPPERY TARP, ETC.

#2) INCLUDED IN BELAY PACKAGE: 1-ROPE GRAB HANDLE, 2-KARABINERS, 1-125 FT. 10 mm STRAIGHT DROP LONG LINE, 1-4 FT. GRAB HANDLE LANYARD.

#3) ATTACH YOUR BELAY LONG LINE TO AN INDEPENDENT ANCHOR POINT UP NEAR WHERE YOU HAVE ANCHORED YOUR *99* SYSTEM ... (BUT ~ IT MUST BE A SEPARATE ANCHOR POINT). IF YOU MUST RUN THE ROPE OVER AN EDGE **BE SURE TO “PAD”** THE EDGE WHERE THE ROPE WILL MAKE CONTACT. USE A PIECE OF PLASTIC, A SLIPPERY TARP, ETC.

#4) DROP THE LONG STRAIGHT LINE TO THE GROUND ... ATTACH THE KARABINER AT THE OPPOSITE END OF THE 4 FT. LANYARD FROM THE HANDLE TO THE “D” RING IN THE MIDDLE OF THE BACK STRAPS OF YOUR HARNESS (OR) CHAIR.

#5) BEFORE YOU START YOUR ASCENT / OR DESCENT ~ BRING THE ATTACHED HANDLE & LANYARD OVER YOUR SHOULDER / AND STORE THE HANDLE IN YOUR LAP OR UNDER ONE OF YOUR LEGS / TILL YOU REACH YOUR WORK SPOT.

#6) ONCE YOU REACH YOUR WORK SPOT ~ FREE BOTH HANDS, & ATTACH THE HANDLE TO THE LONG BELAY LINE ... ARRANGE THE HANDLE WITH NO MORE THAN 3 FT. OF SLACK ... WHEN YOU WISH TO ASCEND / OR DESCEND ~ EITHER REMOVE THE HANDLE / (OR) ADJUST THE HANDLE’S POSITION / STILL / ALLOWING NO MORE THAN 3 FT. OF SLACK.

*****VERY IMPORTANT*** IF THIS FALL STOP *BELAY* SYSTEM IS EVER ACTIVATED & STOPS A FALL ~ ALL COMPONENTS MUST BE REMOVED FROM SERVICE, & DISCARDED & REPLACED AS SOON AS POSSIBLE ...**